


RS Stack



This is the footprint for the standard, straight-line configuration of the RS Stack. For a footprint of this configuration connected to a specific printer, please contact your Lasermix Roll Systems representative.