


RS Stack XL



- Ⓟ Power Location
- - - Service Area
- - - Paper Path

This is the footprint for the standard, straight-line configuration of the RS Stack XL. For a footprint of this configuration connected to a specific printer, please contact your Lasermax Roll Systems representative.